

Power Chairs Reference no. PC030 Cruiser 30



The range and speed of the Cruiser 30 may vary depending on the weight of the user, terrain type, outside temperature and battery charge. We advise that you plan your route to avoid adverse terrain, inclines, kerbs and steps if possible; if this is unavoidable, we do not advise an incline above 5° and a kerb / step above 4cm (1.5"). If it has been agreed that adjustments are necessary, this will need to be done prior to 1pm on the day of the cruise. Please arrange this with the office.

Max user weight	125kg / 19.5st	Kerb climber	No
Total weight	94kg	Seat raising	No
Total width	58cm	Seat recline	Yes (with tools)
Total height	99cm	Backrest recline	Yes (with tools)
Seat width	43 – 50cm	Footplate / standard leg rest / elevating leg rest	Standard leg rests
Seat height	52cm	Footrest length	ТВС
Seat depth	41 – 51cm	Seat angle	TBC
Backrest height	50cm	Backrest angle	TBC
Armrest height	22 – 30cm	Calf supports	Optional
Turning diameter / radius	80cm	Flip up armrest	No
Ground clearance	8cm	Headrest	No
Foldable / comes apart	No	Swivel seat	No
Removable batteries	No	Drive wheel position	Rear wheel
Anchor points / crash tested	Yes / Yes	Battery Amp hour	55Ah
Control options	Joystick (Left / Right side)	Battery type	2x 12V SLA
Swing-away joystick	Yes	Tyre type / colour	Pneumatic / Black
Extra manual brakes	No	Max Speed	4Mph
Lights and hazards fitted	No	Length	101 cm